



# Somfy Controller Programming

## 7301 - Eolis 3D Wirefree Wind Sensor (Jiggly Wiggly)




### Step 1

Remove sensor housing & install 2 AAA batteries  
Make sure **down** button on remote is taking unit **out**


### Step 2

1 Press the programming button #1 then #2 and release each when the unit jogs



## 7302 - Sunis Wirefree Sun Sensor

Light sensing eye



Front View



Back View

### Step 1

Place Sunis (solar powered sun sensor) in a sunny area to charge for 10 min



### Step 2

Completely retract the unit. Press the **Programming Button** (with a pen) on the back of the remote and release when the unit jogs



### Step 3

Press the **Programming Button** (with a pen) on the back of the Sunis and release when the unit jogs



2 - Factory default

### Sensitivity

1 - Most sensitive ~ 9 - Least sensitive

### Final Step

Test the sensor

Instruct customer on use of products and replacing batteries